

TORQUE CONVERTOR / HYD PUMP INSTALLATION

 ITEM	PART NUMBER	QUAN.	DESCRIPTION	Notes
	M365-501-01		TORQUE CONVERTOR KIT	Includes # 1,4,5,6,17 &22
1	M365-501-02	1	TORQUE CONVERTOR	
2	M192-544-01	1	PUMP, HYD, BRAKE, 10 GPM	
3	M350-665-01	1	PUMP, HYD, MAIN, 28 GPM	
4	M365-501-13	1	PUMP, CHARGE	
5	M350-650-01	2	COUPLING ASSEMBLY	
6	M350-500-03	1	SLEEVE, CONVERTOR, CHARGE PUMP	
7	M350-660-02	1	ADAPTER, PUMP, 6 BOLT, OFFSET MOUNT	
8	M350-660-01	1	ADAPTER, PUMP, 6 BOLT	
9	M350-659-01	3	GASKET, PUMP, CONVERTOR, 6 BOLT	
10	M515-500-06	6	SOCKET HEAD CAPSCREW, 3/8-16 X 1 GR8	
11	M150-538-01	6	LOCK WASHER, HIGH COLLAR, 3/8	
12	M515-590-01	12	STUD, 3/8-24 X 3/4 - 3/8-16 X 1/2 1 1/2 OAL GR8	
13	M515-590-02	6	STUD, 3/8-24 X 1 - 3/8-16 X 3/4 2 3/4 OAL GR8	
14	M600-109-01	18	NUTS, 3/8	
15	M600-123-01	18	LOCK WASHER, 3/8	
16	M507-655-01	1	YOKE, OUTPUT, 6C	
17	M510-534-01	1	FLEX PLATE KIT	
18	M515-500-20	8	HEX HEAD CAPSCREW, 3/8-24 X 1 1/2 GR8	Flex Plate to Flywheel
19	M515-530-02	8	NORD LOCK WASHERS, 3/8	Flex Plate to Flywheel
20	M515-500-07	12	HEX HEAD CAPSCREW, M10-1.5 X 60 GR8	Torque Convertor to Bell Housing
21	M150-535-01	12	LOCK WASHER, M10	Torque Convertor to Bell Housing
22	M350-592-01	1	TRANSMISSION FILTER ASSEMBLY	Not Shown Ref Section 5-32